

Montage- und Gebrauchsanweisung



GB Assembly and Usage Instructions

PL Ćnstrukcja montażu i użytkowania

F Instructions de montage et d'utilisation

RUS Инструкция по монтажу и эксплуатации

DE: Dieses Produkt enthält eine Lichtquelle der Ennergieeffizienzklasse E

EN: This product contains light source(s) of energy efficiency class(es) E

FR: Ce produit contient une/des source(s) lumineuse(s) de classe(s) d'efficacité énergétique E

PL: Produkt zawiera źródła światła o klasie(-ach) efektywności energetycznej E


RU: Это изделие содержит источники света с классом энергопотребления E

B-LEUCHTEN Vertriebs GmbH & Co. KG
Hüttenstr.4
D-59759 Amsberg
Info@b-leuchtenvertrieb.de

50462-1-XX



NACH VDE-VORSCHRIFT 0100 DARF DIESE LEUCHTE NUR VON EINER FACHKRAFT (Z.B. ELEKTRIKER) MONTIERT WERDEN
LED NUR DURCH DEN HERSTELLER TAUSCHBAR
SOLLTEN DICHTUNGEN FEHLEN ODER BESCHÄDIGT SEIN DARF LEUCHTE NICHT IN FUNKTION GENOMMEN WERDEN
ERSATZTEILE SIND ÜBER DEN HERSTELLER ZU BEZIEHEN



Dieses Produkt enthält eine Lichtquelle der Energieeffizienzklasse E.

GERMAN

Durch kurzes Betätigen des Tasters ändern Sie die Lichtquelle:
1x drücken und es leuchtet nur die Seite mit der Linse, drücken Sie den Taster wieder, leuchtet nur die Seite mit der matt Oberfläche. Durch erneutes Drücken schalten Sie beide Lichtquellen an.
Durch eine weitere Betätigung des Tasters schalten Sie die Leuchte aus.

Halten Sie den Taster länger gedrückt, so dimmen Sie die gerade eingeschaltete Lichtquelle(n).

ENGLISH

Briefly press the button to change the light source:
Press once and only the side with the lens lights up, press the button again and only the side with the matt surface lights up. Press again to switch on both light sources.
Press the button again to switch the light off.

If you keep the button pressed for longer, you dim the light source(s) that are currently switched on.